


MIJ-12

The Water Proof Logger Manual



Environmental Measurement Japan, CO., LTD.

2-52-42 Takamidai, Fukuoka-city Higashiku, Fukuoka 811-0215, Japan

TEL +81-92-608-6412

FAX +81-92-985-7844



MIJ-12 The Water Proof Logger Manual

Unpacking


MIJ-12 is shipped fully assembled. Make sure that all of the following items are included.

- IP68 Case
- LR5041 or 5042 Datalogger
- LR9802 cable
- Silica Gel Bag
- PR-01(Preheat Power Supply Board;if your sensor need preheat function)
- Communication Adapter LR5091 or 5092(Only if you do not have one)

MIJ-12 Preheat Version: How to wire sensor and logger

Connect sensor to PR-01

Sensors




Connect Logger (LR5042) to PR-01



- Connect voltage input- (black) to Sig-
- Connect voltage input+ (red) to Sig+
- Connect GND (for preheat; white) to GND
- Connect Preheat (yellow) to PRH

Typical sensor that require preheat

Soil Moisture Snesor



(Simultaneous temperature measurement requires 2 channels, so temperature measurement is not possible with MIJ-12)




(For the EC5, please be careful not to connect the preheat to 12V)


Dendrometers



MIJ-02 Type3 Rotary



MIJ-02 Type2 LMS
MIJ-02 Type2 LMM



Environmental Measurement Japan, CO., LTD.

2-52-42 Takamidai, Fukuoka-city Higashiku, Fukuoka 811-0215, Japan


TEL +81-92-608-6412

FAX +81-92-985-7844



PR-01 Sensor Preheat Power Supply Board

The PR-01 is a board that supplies the necessary power to the sensor from 4 AA batteries. The PR-01 has two types of voltage output, [2.5V and 12V] or [5V and 12V], so you can choose according to the sensor. The instantaneous capacity of each voltage output is 80mA. For general use, the preheat time is 1 second and the interval is 10-30 minutes. When using AA alkaline batteries, the capacity is 2000mAh, so generally four AA alkaline batteries can drive the sensor for over a year.



[2.5V&12V]

SM150T, ML3, EC5, 10HS etc.




[5V&12V]

EMJ Dendrometer

There is a red sticker on the board of [5V&12V]

MIJ-12 Preheat Less Version: How to wire Sensor and Logger

I will explain how to wire the MIJ-12 preheatless. No PR-01 base is required as it does not require preheating.




Typical sensor that do not require preheat

PAR Sensor




MIJ-14/K2



Soil Oxygen sensor



MIJ-03




Environmental Measurement Japan, CO., LTD.
2-52-42 Takamidai, Fukuoka-city Higashiku, Fukuoka 811-0215, Japan
TEL +81-92-608-6412
FAX +81-92-985-7844



Caution

Please note the following when using the MIJ-12 in the field.

- Open the zipper of the included silica gel and reinsert it into the MIJ-12.
- Tighten the cover of MIJ-12 tightly.




Trouble Shooting

No data available

1:PR-01 not working?

- Are the battery polarities correct? (Battery polarity +,- may be inserted in the opposite direction by mistake.)
- Press the record button on the logger and try to move the sensor (for a soil moisture meter, grab the pin, etc.), and will the PR-01 LED light up at that time?
- Try shorting PR-01's GND and PRH with tweezers. Does the LED light up at this time?




- If there are no problems with all of the above, it can be said that the PR-01 is almost not broken.

We recommend replacement for obvious failures that can be found without the above tests (the base is clearly rotten, etc.).

2.Are the LR5042 settings correct?

- Is the LR5042's preheat set to OFF?



If you are using a sensor that requires preheating, be sure to set the preheating to 1 second (recommended).



Environmental Measurement Japan, CO., LTD.
2-52-42 Takamidai, Fukuoka-city Higashiku, Fukuoka 811-0215, Japan
TEL +81-92-608-6412
FAX +81-92-985-7844




Trouble Shooting

3. Is there any remaining battery for PR-01 or Logger?



replace with new battery



If you still have problems after solving 1 to 3, please contact us.



Setting:Logger LR5042 or LR5041

Basically, the following contents are set at the time of shipment.

- Rec Interval: 10min
- Start method: Button operation
- Stop method: Button operation (One-time)
- Rec mode: instantaneous
- Preheat: 1sec (Only if your sensor need preheat)

How to set

- 1.Plug the communication adapter LR5091 or LR5092 into your PC USB port.
- 2.The LR5000 Utility screen will appear on your PC. Please change various settings arbitrarily in the recording method tab.(The factory setting is recommended.)





Environmental Measurement Japan, CO., LTD.
2-52-42 Takamidai, Fukuoka-city Higashiku, Fukuoka 811-0215, Japan
TEL +81-92-608-6412
FAX +81-92-985-7844




Setting:Logger LR5042 or LR5041

3.Click the measurement method tab to set preheat ON/OFF.



If you use the MIJ-12 preheat version, set the preheat option. (We recommend 1 second.)



Note: Please set preheat to OFF when using the MIJ-12 preheatless version.

4.Finally, click the Submit Settings button to complete.




Please refer to the HIOKI website for details of functions.
https://www.hioki.com/global/products/compact-data-loggers/compact/id_5920

Measurement start/stop/data collection

Start Measurement

1. Install the sensor. Press the Record/Stop key for more than 2 seconds. Press until “REC” appears on the display and it stops flashing and stays lit.




Environmental Measurement Japan, CO., LTD.
2-52-42 Takamidai, Fukuoka-city Higashiku, Fukuoka 811-0215, Japan
TEL +81-92-608-6412
FAX +81-92-985-7844




Measurement start/stop/data collection

2.The measurement screen is displayed 1 second after REC lights up. Measurement is started at this time.




Stop Measurement




Press the record/stop button for 2 seconds or more, and stop is completed when "REC" disappears after blinking.

Data Collecting steps

1.Connect the LR5091 to your PC.



2.Place the LR5092 on top of the LR5091 communication adapter. (Place the LR5042 with the DISPLAY side facing down.)



Please refer to the HIOKI official page or the attached manual for details



Environmental Measurement Japan, CO., LTD.
2-52-42 Takamidai, Fukuoka-city Higashiku, Fukuoka 811-0215, Japan
TEL +81-92-608-6412
FAX +81-92-985-7844

